Futaba

Compatibility table 2.4GHz Air Transmitter ⇔ receiver

Trans-mitter	System	Receiver (FASST 7ch)	Receiver (FASST Multi ch)	Receiver (FASST 7ch/ FASST Multi ch)	Receiver (FASSTest)	Receiver (T-FHSS AIR)	Receiver (T-FHSS AIR Mono)	Receiver (S-FHSS)
		R607FS R616FFM R617FS R6004FF R6106HF R6106HFC	R608FS R6008HS R6014FS R6014HS R6108SB R6208SB R7018SB R7114SB	R6202SBW R6203SB R6203SBE R6303SB R6303SBE R7006SB R7106SB R7108SB	R7003SB R7103SB R7006SB R7106SB R7008SB R7018SB R7108SB CGY760R R7114SB	R3001SB R3004SB R3006SB R3008SB CGY760R	R3106GF R3206SBM (Telemetry not available)	R2001SB R2106GF R2006GS R2008SB R2000SBM
T32MZ T18MZ-WC T18SZ T16SZ FX-36	FASST 7ch	OK	–	OK	–	–	–	–
	FASST Multi ch	–	OK	OK	–	–	–	–
	FASSTest	–	–	–	OK	–	–	–
	T-FHSS AIR	–	–	–	–	OK	OK	–
	S-FHSS	–	–	–	–	–	–	OK
T16IZ	FASSTest	–	–	–	OK	–	–	–
	T-FHSS AIR	–	–	–	–	OK	OK	–
	S-FHSS	–	–	–	–	–	–	OK
T18MZ T14SG FX-22	FASST 7ch	OK	–	OK	–	–	–	–
	FASST Multi ch	–	OK	OK	–	–	–	–
	FASSTest	–	–	–	OK	–	–	–
	S-FHSS	–	–	–	–	–	–	OK
T10J T12K T6K	T-FHSS AIR	–	–	–	–	OK	OK	–
	S-FHSS	–	–	–	–	–	–	OK
T6L	T-FHSS AIR Mono (Telemetry not available)	–	–	–	–	OK	OK	–
T6EX T7C	FASST 7ch	OK	–	OK	–	–	–	–
T6J T8J	S-FHSS	–	–	–	–	–	–	OK
T8FG T8FGS FX-20	FASST 7ch	OK	–	OK	–	–	–	–
	FASST Multi ch	–	OK	OK	–	–	–	–
T10CG	FASST 7ch	OK	–	OK	–	–	–	–
	FASST 10ch	–	OK	OK	–	–	–	–

Module	System	Receiver (FASST 7ch)	Receiver (FASST Multi ch)	Receiver (FASST 7ch/ FASST Multi ch)	Receiver (FASSTest)	Receiver (T-FHSS AIR)	Receiver (T-FHSS AIR Mono)	Receiver (S-FHSS)
		R607FS R616FFM R617FS R6004FF R6106HF R6106HFC	R608FS R6008HS R6014FS R6014HS R6108SB R6208SB R7018SB R7114SB	R6202SBW R6203SB R6203SBE R6303SB R6303SBE R7006SB R7106SB R7108SB	R7003SB R7103SB R7006SB R7106SB R7008SB R7018SB R7108SB CGY760R R7114SB	R3001SB R3004SB R3006SB R3008SB CGY760R	R3106GF R3206SBM (Telemetry not available)	R2001SB R2106GF R2006GS R2008SB R2000SBM
TM8 Module	FASST 7ch	OK	–	OK	–	–	–	–
	FASST 8ch	–	OK	OK	–	–	–	–
TM10 Module	FASST 7ch	OK	–	OK	–	–	–	–
	FASST 10ch	–	OK	OK	–	–	–	–
TM14 Module	FASST 7ch	OK	–	OK	–	–	–	–
	FASST Multi ch	–	OK	OK	–	–	–	–
TM-FH Module	S-FHSS	–	–	–	–	–	–	OK

Futaba
Compatibility table 2.4GHz Car Transmitter ⇔ receiver

Trans-mitter	System	Receiver F-4G R404SBS R404SBS-E	Receiver T-FHSS-SR/T-FHSS R334SBS R334SBS-E	Receiver T-FHSS R324SBS R314SB R314SB-E R304SB R304SB-E	Receiver FASST-C2 R614FS R614FF R614FF-E R604FS R604FS-E	Receiver S-FHSS/FHSS R202GF R203GF R204GF-E R214GF-E R2104GF R2008SB	Receiver FHSS R2004GF R603GF	KYOSHO MINI-Z T-FHSS MINI-Z RA-42
T10PX	F-4G	OK	–	–	–	–	–	–
	T-FHSS-SR	–	OK	–	–	–	–	–
	T-FHSS	–	OK	OK	–	–	–	–
	MINI-Z T-FHSS	–	–	–	–	–	–	OK
	S-FHSS	–	–	–	–	OK	–	–
T7PX(R) T7XC	T-FHSS-SR	–	OK	–	–	–	–	–
	T-FHSS	–	OK	OK	–	–	–	–
	MINI-Z T-FHSS(V4.0~)	–	–	–	–	–	–	OK
	FASST-C2	–	–	–	OK	–	–	–
	S-FHSS	–	–	–	–	OK	–	–
T4PV	T-FHSS	–	OK	OK	–	–	–	–
	S-FHSS	–	–	–	–	OK	–	–
T4PM	T-FHSS-SR	–	OK	–	–	–	–	–
	T-FHSS	–	OK	OK	–	–	–	–
	MINI-Z T-FHSS	–	–	–	–	–	–	OK
	S-FHSS	–	–	–	–	OK	–	–
T3PV	T-FHSS	–	OK	OK	–	–	–	–
	S-FHSS	–	–	–	–	OK	–	–
	FHSS	–	–	–	–	OK	OK	–
T4GRS	T-FHSS	–	OK	OK	–	–	–	–
	S-FHSS	–	–	–	–	OK	–	–
	FHSS	–	–	–	–	OK	OK	–
T4YWD	FHSS	–	–	–	–	OK	OK	–
T2HR	FHSS	–	–	–	–	OK	OK	–

Transmitter Module	System	Receiver T-FHSS-SR/T-FHSS R334SBS R334SBS-E	Receiver T-FHSS R324SBS R314SB R314SB-E R304SB R304SB-E	Receiver FASST-C2 R614FS R614FF R614FF-E R604FS R604FS-E	Receiver FASST-C1 R603FS R603FF	Receiver S-FHSS/FHSS R202GF R203GF R204GF-E R214GF-E R2104GF R2008SB	Receiver FHSS R2004GF R603GF
T4PX	T-FHSS	OK	OK	–	–	–	–
	FASST-C2	–	–	OK	–	–	–
	S-FHSS	–	–	–	–	OK	–
T4PK (T4PKS) (T4PKS-R)	FASST-C1	–	–	–	OK	–	–
	FASST-C2	–	–	OK	–	–	–
T4PLS	T-FHSS	OK	OK	–	–	–	–
	S-FHSS	–	–	–	–	OK	–
	FHSS	–	–	–	–	OK	OK
T4PL	S-FHSS	–	–	–	–	OK	–
	FHSS	–	–	–	–	OK	OK
T3PRKA	FHSS	–	–	–	–	OK	OK
T3PM (T3PM-MX)	FASST-C1	–	–	–	OK	–	–
T3GR	FASST-C1	–	–	–	OK	–	–
T3PL	FHSS	–	–	–	–	OK	OK
PK-FSM2.4G (Module)	FASST-C1	–	–	–	OK	–	–